
Bulk CO2 Troubleshooting Guide



Is your CO2 alarm going off? Open any windows and doors in the area to allow the gas to escape, evacuate the area and call for service immediately!

Bulk CO2 Troubleshooting Guide

The 0-200 PSI gauge should be set between 90-120 psi
The 0-400 PSI gauge should read between 125-300 psi

